

ROCKFORD

Drive Line



***CV Joints, Splined Stubs, Boot Kits
& Crimping Fixtures***

MANUFACTURER OF DRIVELINE COMPONENTS
1500 11TH AVENUE ROCKFORD, ILLINOIS 61104
PHONE (815) 962-1411 FAX (815) 965-4857
RockfordDriveLine.com

ROCKFORD

Drive Line

TABLE OF CONTENTS

	PAGE
CRIMPING FIXTURES	13-14
SPLINED STUBS	9
HIGH SPEED BOOT KITS	10-12
HIGH SPEED CV JOINTS	4-8
REFERENCE GUIDE	15

Notice: The data contained in this catalog has been thoroughly checked for accuracy, however we cannot assume any responsibility for errors, omissions or typographical mistakes that may appear.

All data is property of ©Rockford Drive Line and may not be duplicated or used in any way without written authorization.

High Speed CV Joints...

Rockford's NEW "FULLY LOADED" C.V. joints are manufactured to meet the design requirements of the original equipment manufacturer. The new assembly includes our super-strength OE designed housing with precision-engineered internal components and a new boot, end cap, grease and hardware required to do the job right.

Rkfd No.

Applications Years

361-80 (Rear Joint) - Fixed Design

Jeep Grand Cherokee..... 1999-2004
Jeep Liberty 2002-2007

Note: This joint appears to be the same as the 361-80D but the inner race is longer on this application.



361-80B (Front Joint) - Plunge Design

Jeep Grand Cherokee..... 1999-2000
Jeep Grand Cherokee- 4.0L..... 2001-2004
Jeep Liberty 2002-2007



361-80D

Dodge Dakota (4WD)..... 2001-2007
Dodge Durango (4WD) 2001-2003
Jeep Commander 2006-2010
Jeep Grand Cherokee..... 2005-2006
Jeep Grand Cherokee (Exc. 3.0L) 2007-2010
Mitsubishi Raider 2006-2007

Note: This joint appears to be the same as the 361-80 but the inner race is shorter on this application.



High Speed CV Joints...



421-80

Chevrolet Astro Van (AWD) 1992-1998
Chevrolet Blazer (AWD Models) ... 1995-1997
GMC Jimmy (AWD) 1995-1997
GMC Safari Van (AWD) 1992-1998
Pontiac 6000 (AWD) 1989-1990
Oldsmobile Bravada 1991-1997



421-80C

Chevrolet Camaro V6 1993-2002
Pontiac Firebird V6 1993-2002



424-80

Jeep Grand Cherokee 1993-1998



427-80 (27 Teeth)

Ford Explorer 1997-2005
Ford Ranger (4WD) 1998-2011
Lincoln Aviator (4WD) 2003-2005
Mazda B-3000 Pickup (4WD) 1998-2003
Mazda B-4000 Pickup (4WD) 1998-2010
Mercury Mountaineer 1997-2005

High Speed CV Joints...

429-80

Chevy Blazer ¹	1998-2005
Chevy Blazer (4WD)	1995-1997
Chevy S-10 Pickup ¹	1997-2004
Chevy S-10 Pickup (4WD)	1994-1996
GMC Envoy ¹	1998-2000
GMC Jimmy ¹	1998-2005
GMC Jimmy (4WD)	1995-1997
GMC S-15 Pickup ¹	1997-2004
GMC S-15 Pickup (4WD)	1994-1996
Isuzu Hombre (4WD)	1998-2000



¹ - Application is W/Electronic Transfer Case

429-80A

Buick Rainier.....	2004-2007
Chevy Astro & GMC Safari	1999-2005
Chevy Blazer & GMC Jimmy ²	1998-2005
Chevy S-10 Pickup ²	1997-2004
Chevy Trailblazer	2002-2009
GMC Envoy ²	1999-2009
GMC S-15 Pickup & Sonoma ²	1997-2004
Isuzu Ascender	2003-2008
Oldsmobile Bravada.....	1998-2004
Saab 9-7X	2005-2006



² - Application is W/Push Button Transfer Case

435-80 (28 Teeth)

Dodge Ram 1500 Pickup	2002-2006
Dodge Durango.....	2004-2006



437-80

Chevrolet Colorado	2004-2011
GMC Canyon	2004-2011
Hummer H3.....	2006-2010
Isuzu I350	2006
Isuzu I370	2007-2008



High Speed CV Joints...



450-80

Saturn Vue (AWD)..... 2002-2007



451-80

Pontiac Solstice 2006-2010
Saturn Sky 2007-2009



452-80

Chevrolet Equinox..... 2005-2006
Pontiac Torrent..... 2006



454-80

Ford Escape (AWD) Exc. Hybrid) . 2005-2007
Ford Escape (AWD) 2001-2004
Mercury Mariner 2005-2007
Mazda Tribute 2001-2006

High Speed CV Joints...

456-80 - (Fixed End)

Ford Mustang (4.6L 3V) 2005-2010



456-80B - (Plunge End)

Ford Mustang (4.6L 3V) 2005-2010



457-80 - (Fixed End)

Ford Expedition 2007-2011
Ford F150 6 spd (6R80) 2009-2011
Ford F150 5.0L & 6.2L 2011
Ford F150 Raptor 2010-2011
Lincoln Navigator 2007-2011



457-80B - (Plunge End)

Ford Expedition 2007-2011
Ford F150 6 spd (6R80) 2009-2011
Ford F150 5.0L & 6.2L 2011
Ford F150 Raptor 2010-2011
Lincoln Navigator 2007-2011



Replacement Splines for High Speed CV Joints...



RDL Part Number	Tooth Count	Fits Tube Dia/Wall	Butt Diameter	End of Spline to Weld
361-31	25T/1.075	OEM	1.615	4.750*
361-31A	25T/1.075	2.000 / .120	1.765	4.250
361-31B	25T/1.075	OEM	1.615	8.875*
361-31C	25T/1.075	2.000 / .120	1.765	8.375
361-31D	25T/1.075	OEM	1.788	4.750*
361-31E	25T/1.075	2.000 / .120	1.765	4.250
421-31	22T/0.995	2.000 / .120	1.765	4.375
421-31A	22T/0.995	1.250 / .189	0.890	4.375
421-31C	DISCONTINUED			
427-31	27T/1.125	2.000 / .120	1.765	4.875
429-31	22T/0.995	2.000 / .083	1.850	4.375
435-31	28T/1.195	OEM	2.215	5.250*
435-31A	28T/1.195	2.500 / .083	2.344	4.750
437-31	34T/1.085	2.000 / .065	1.889	4.500

* Stub made 1/2" longer than OEM to allow for cut off

CV Joint Kit	Stub to Use	CV Joint Kit	Stub to Use
361-80	361-31 / 361-31A	427-80	427-31
361-80B	361-31B / 361-31C	429-80	429-31
361-80D	361-31D / 361-31E	429-80A	429-31 / 421-31A
421-80	421-31 / 421-31A	435-80	435-31 / 435-31A
421-80C	421-31C (DISCONTINUED)	437-80	437-31

High Speed Boot Kits...

Over the years a number of original equipment manufacturers have introduced drive-shafts that incorporate cage & ball or cross groove constant velocity joint technology. According to many of these manufacturers, these driveshafts are non-repairable and no replacement components are available. Rockford supplies **HIGH SPEED BOOTS** for a majority of these "non-repairable" applications.

Boot Kits include:

1-Boot Assembly, End Cap, Grease, Installation Instructions & Any Misc. Hardware Required.

THE INDUSTRY'S BROADEST COVERAGE

Kit Number	Application	Year
320-21C	BMW 525i BMW 533i BMW 535i BMW 635Csi BMW 735iL.....	1989-1992 1983-1984 1985-1992 1983-1986 1989-1991
361-21*	Jeep Grand Cherokee (4WD) Jeep Liberty- (Rear Joint)- Fixed Design	1999-2004 2002-2007
361-21B*	Jeep Grand Cherokee (4WD) Jeep Liberty- (Front Joint)- Plunge Design	1999-2004 2002-2007
361-21D*	Dodge Dakota (4WD)..... Dodge Durango (4WD) Jeep Commander (4WD) Jeep Grand Cherokee (4WD) Mitsubishi Raider (4WD)	2001-2007 2001-2003 2007-2010 2005-2010 2006-2007
406-21	(Fits 1210 Series Yokes & 2" Tube)	
408-21	Ford Bronco II (Slip Yoke) Ford Ranger W/108" WB (Slip Yoke) (Fits 1210 Series Yokes & 2 1/2" Tube)	1983-1985 1983-1989
419-21	Chevrolet Astro Van (AWD)..... Ford Bronco II (<i>Exc. 6/89-90 2WD</i>) GMC Safari Van (AWD) Jeep Cherokee..... Jeep Wagoneer.....	1990-1991 1985-1990 1990-1991 1984-1987 1984-1987
419-21A	GMC Syclone..... GMC Typhoon.....	1991-1993 1991-1993

*Crimping Fixture is available but not required to service these kits (see pgs 13-14)

THE INDUSTRY'S BROADEST COVERAGE

Kit Number	Application	Year
420-21	Ford Bronco II 2WD (6/89-up).....	1989-1990
421-21*	Chevrolet Astro Van (AWD).....	1992-1998
	Chevrolet Blazer (AWD).....	1995-1997
	GMC Jimmy (AWD).....	1995-1997
	GMC Safari Van (AWD)	1992-1998
	Pontiac 6000 (AWD)	1988-1990
	Oldsmobile Bravada.....	1991-1997
421-21C	Chevrolet Camaro V6	1993-2002
	Pontiac Firebird V6	1993-2002
424-21*	Crysler Town & Country (AWD).....	2001-2004
	Dodge Caravan (AWD)	2001-2004
	Jeep Grand Cherokee Auto Trans	1993-1998
427-21A	Ford Explorer (4WD).....	1997-2005
	Ford Ranger (4WD)	1998-2011
	Lincoln Aviator (4WD)	2003-2005
	Mazda B-3000 Pickup (4WD)	1998-2003
	Mazda B-4000 Pickup (4WD)	1998-2010
	Mercury Mountaineer (4WD).....	1997-2005
429-21*	Buick Rainier.....	2004-2007
	Chevrolet Astro Van (AWD).....	1999-2005
	Chevrolet Blazer (4WD)	1995-2005
	Chevrolet Trailblazer	2002-2009
	Chevrolet S-10 Pickup (4WD).....	1994-2004
	GMC Envoy.....	1998-2009
	GMC Jimmy (4WD).....	1995-2005
	GMC Safari Van	1999-2005
	GMC S-15 Pickup (4WD).....	1994-2004
	Isuzu Ascender (4WD).....	2003-2008
	Isuzu Hombre (4WD)	1998-2000
	Oldsmobile Bravada (4WD)	1998-2004
	Saab 9-7X	2005-2006
435-21*	Dodge Ram 1500 Pickup	2002-2006
	Dodge Durango.....	2004-2006
437-21*	Chevrole Colorado	2004-2011
	GMC Canyon	2004-2011
	Hummer H3.....	2006-2010
	Isuzu I350	2006
	Isuzu I370	2007-2008
450-21*	Saturn Vue (AWD)	2002-2007

*Crimping Fixture is available but not required to service these kits (see pgs 13-14)


THE INDUSTRY'S BROADEST COVERAGE

Kit Number	Application	Year
451-21	Pontiac Solstice Saturn Sky	2006-2010 2007-2009
452-21*	Chevrolet Equinox..... Pontiac Torrent.....	2005-2006 2006
454-21*	Ford Escape..... Mercury Mariner..... Mazda Tribute	2001-2007 2005-2007 2001-2006
456-21	Ford Mustang (4.6L 3V)- Fixed End.....	2005-2010
456-21B	Ford Mustang (4.6L 3V)- Plunge End	2005-2010
457-21	Ford Expedition- Fixed End	2007-2011
	Ford F150 5.0L & 6.2L- Fixed End.....	2010-2011
	Ford F150 6 Spd (6R80)- Fixed End.....	2009-2011
	Ford F150 Raptor- Fixed End	2010-2011
	Lincoln Navigator- Fixed End.....	2007-2011
457-21B	Ford Expedition- Plunge End	2007-2011
	Ford F150 5.0L & 6.2L- Plunge End	2010-2011
	Ford F150 6 Spd (6R80)- Plunge End	2009-2011
	Ford F150 Raptor- Plunge End	2010-2011
	Lincoln Navigator- Plunge End	2007-2011
804-21*	BMW 735i (Stud Style CV)..... BMW 735iL (Stud Style CV)..... BMW 750iL (Stud Style CV)..... BMW M5 (Stud Style CV)	1987-1992 1988-1989 1988-1991 1991
804-21C	BMW 735i (Thru-Bolt Style CV)	1987-1992
	BMW 735iL (Thru-Bolt Style CV)	1988-1989
	BMW 750iL (Thru-Bolt Style CV)	1988-1991
	BMW M5 (Thru-Bolt Style CV)	1991
805-21A	Mazda MPV	1989-1991
	Subaru SVX	1992-1993
806-21A	Toyota Camry (All-Trac)	1988-1991
808-21A	Nissan 300ZX Twin Turbo..... BMW 740i W/ E32 Body Style	1990-1996 1993-1994
	BMW 740iL W/ E32 Body Style	1993-1994

*Crimping Fixture is available but not required to service these kits (see pgs 13-14)

High Speed Boot Crimping Fixtures...

Rockford now offers a wide selection of fixtures that will professionally crimp high speed DURA-BOOTS onto the original equipment housing. Each fixture assures you of a positive seal that keeps lubricants in and contaminates out.




Crimping Fixture	Boot Kit Number	Applications	Years
100-14TG	421-21	Chevrolet Astro Van (AWD) Chevrolet Blazer (AWD) GMC Jimmy (AWD) GMC Safari Van (AWD) Pontiac 6000 (AWD) Oldsmobile Bravada	1992-1998 1995-1997 1995-1997 1992-1998 1989-1990 1991-1997
100-14TN	804-21	BMW 735i (Stud Style CV) BMW 735iL (Stud Style CV) BMW 750iL (Stud Style CV) BMW M5 (Stud Style CV)	1987-1992 1988-1989 1988-1991 1991
100-14TO	424-21	Dodge Caravan (AWD)- Plunging Joint..... Chrysler Town & Country (AWD)- Plunging Joint Jeep Grand Cherokee Auto Trans <u>Crimps the boot flange & end cap in one step</u>	2001-2004 2001-2004 1993-1998
100-14TP	429-21	Buick Rainier Chevrolet Astro Van (AWD) Chevrolet Blazer (4WD) Chevrolet Trailblazer Chevrolet S-10 Pickup (4WD) GMC Envoy GMC Jimmy (4WD) GMC Safari Van GMC S-15 Pickup (4WD) Isuzu Ascender (4WD) Isuzu Hombre (4WD) Oldsmobile Bravada (4WD) Saab 9-7X	2004-2007 1999-2005 1995-2005 2002-2009 1994-2004 1998-2009 1995-2005 1999-2005 1994-2004 2003-2008 1998-2000 1998-2004 2005-2006
100-14TQ	361-21	Jeep Grand Cherokee Jeep Liberty- (Rear Joint)- Fixed Design..... <u>Crimps the boot flange & end cap in one step</u>	1999-2004 2002-2007

High Speed Boot Crimping Fixtures...

Crimping Fixture	Boot Kit Number	Applications	Years
100-14TQ	361-21D	Dodge Dakota (4WD) Dodge Durango (4WD)..... Jeep Commander (4WD) Jeep Grand Cherokee (4WD)..... Mitsubishi Raider (4WD)	2001-2007 2001-2003 2007-2010 2005-2010 2006-2007
		<i>Crimps the boot flange & end cap in one step</i>	
100-14TR	361-21B	Jeep Grand Cherokee (4WD)..... Jeep Liberty- (Front Joint)- Plunge Design.....	1999-2004 2002-2007
		<i>Crimps the boot flange & end cap in one step</i>	
100-14TS	437-21	Chevrolet Colorado GMC Canyon..... Hummer H3 Isuzu I350..... Isuzu I370.....	2004-2011 2004-2011 2006-2010 2006 2007-2008
100-14TT	435-21	Dodge Ram 1500 Pickup Dodge Durango	2002-2006 2004-2006
100-14TU	450-21	Saturn Vue (AWD)	2002-2007
100-14TV	452-21	Chevrolet Equinox Pontiac Torrent	2005-2006 2006
100-14TW	454-21	Ford Escape Mercury Mariner Mazda Tribute.....	2001-2007 2005-2007 2001-2006

Reference Guide...

A handy guide for you to use when looking for the crimping fixture needed for a High Speed CV Joint or Boot Kit. Use it for finding what Boot Kit is used for a CV Joint or even when you want to know what spline to use when making a driveshaft assembly.



High Speed CV Joint Kits	Crimping Fixtures	Replacement Splines	High Speed CV Boot Kits
***	***	***	320-21C
361-80	100-14TQ	361-31 361-31A	361-21
361-80B	100-14TR	361-31B 361-31C	361-21B
361-80D	100-14TQ	361-31D 361-31E	361-21D
***	***	***	406-21
***	***	***	408-21
***	***	***	419-21
***	***	***	419-21A
***	***	***	420-21
421-80	100-14TG	421-31 421-31A	421-21
421-80C	***	421-31C	421-21C
424-80	100-14TO	***	424-21
427-80	***	427-31	427-21A
429-80	100-14TP	429-31	429-21
429-80A	100-14TP	429-31 421-31A	429-21
435-80	100-14TT	435-31 435-31A	435-21
437-80	100-14TS	437-31	437-21
450-80	100-14TU	***	450-21
451-80	***	***	451-21
452-80	100-14TV	***	452-21
454-80	100-14TW	***	454-21
456-80	***	***	456-21
456-80B	***	***	456-21B
457-80	***	***	457-21
457-80B	***	***	457-21B
***	100-14TN	***	804-21
***	***	***	804-21C
***	***	***	805-21A
***	***	***	806-21A
***	***	***	808-21A

MANUFACTURER OF DRIVELINE COMPONENTS
1500 11TH AVENUE ROCKFORD, ILLINOIS 61104
PHONE (815) 962-1411 FAX (815) 965-4857
RockfordDriveLine.com